



25 POSSIBLE POINTS SMAW 1/8" E7018 MAKE SURE ALL WELDS OVERLAP EACH OTHER 50% AND CAN'T RISE MORE THAN 1/8" ABOVE TOP PLATE. BACKING STRAP MUST EXTEND 1" BEYOND EACH EDGE AND BE TACKED AT LEAST IN FOUR SPOTS, TWO ON EACH SIDE.

